

Sakurafubuki 3rd Install and start manual

sakurafubuki3rd

Sakurafubuki3rd provides Multicast file transfer service over the satellite UDL link

STEP1

COPY SAKURAFUBUKI3rd RPM FILE FROM CD-ROM

```
#mount /mnt/cdrom  
#cd /mnt/cdrom/sakura3  
#cp imlsdds-rc3.030219-1.i386.rpm /soi/soiasia/
```

STEP2

EXTRACT and COMPILE

```
#cd /soi/soiasia/  
#rpm -i imlsdds-rc3.030219-1.i386.rpm
```

STEP3

How to start MCDD program

```
# /usr/local/implsdds/mcdd -f recv.ini
```

- Normally mcdd program start automatically during the computer's start-up process.

You must restart at which time you configured recv.ini file.

Option

-f : configuration file specification
specify the file for the configuration

If you don't specify the files for the configuration. program uses imslsdds.ini in current directory.